



Congratulations on purchasing your Fridge-tag® 3 device and SMS data plan.

You are now three steps away from completing your device activation.

Step 1. Submit your Fridge-tag® 3 device custom profile.

Step 2. Complete device installation instructions.

Step 3. Turn on and activate your device.



Step 1. Fill out your Fridge-tag® 3 device custom profile

We have made activating your device very easy. First determine the custom temperature monitoring settings for your device(s). Once you have determined your settings, submit them to our team for us to update your device profile for you. You can use the PDF form on the next page to collect your settings. If you have any questions about your settings, please don't hesitate to call us at 1 (508) 366 – 0084.

Submit your device profile settings by going to:

www.berlingerusa.com/deviceprofile

Once you have filled on the form on the webpage linked above, Berlinger USA will notify you when your device settings have been updated.

Fridge-tag® 3 Device Custom Profile PDF Form:

Please note, all alarms are set in Celsius even if Fahrenheit is chosen as the display temperature unit. Notifications are sent by SMS to all subscribed users for all alarms and warnings, but only alarms are reported in the LCD display. If you have any questions about your settings, please don't hesitate to call us at 1 (508) 366 – 0084.

Order Number: _____

Name of Setting Profile (e.g. refrigerator or freezer): _____

Name of Administrator: _____

Email of Administrator: _____

Company: _____

Time Zone: Eastern Central Mountain Pacific

Administrator's cell phone number: _____

User cell phone numbers (max 5): _____

Fridge-tag® 3 Device(s) Serial Number(s) (Please use commas to separate):

Temperature Monitoring Settings:

_____ High Alarm Temperature (-40.0 to +55.0 °C in 0.1 increments)

_____ High Alarm Duration (0 = disable to 1440 minutes in 1 min. increments; suggestion: one minute to indicate alarm limit has been breached)

_____ Low Alarm Temperature (-40.0 to +55.0 °C in 0.1 increments)

_____ Low Alarm Duration (0 = disable to 1440 minutes in 1 min. increments)

_____ High Warning Temperature (suggestion: same as high alarm; -40.0 to +55.0 °C in 0.1 increments)

_____ High Warning Duration (0 = disable to 1440 minutes in 1 min. increments)

_____ Low Warning Temperature (suggestion: same as low alarm; -40.0 to +55.0 °C in 0.1 increments)

_____ Low Warning Duration (0 = disable to 1440 minutes in 1 min. increments)

Submit your device profile settings by going to:

www.berlingerusa.com/deviceprofile

Step 2. Complete device installation instructions

1. When you receive the shipment, the first thing you should do is place the glycol bottle containing the external sensor probe in the respective refrigerator and freezer units.
2. Next attach the Fridge-tag® 3 device with LCD on the outside of the cabinet either on the door near the hinge or the side near the hinge using the supplied Velcro strips.
3. Plug the power adapter into an electrical outlet and connect one end of the USB cable into the power adapter and the other end into the USB connector on the Fridge-Tag 3 and leave it connected to continually charge the batteries.
4. Wait two hours before connecting the Fridge-tag® 3 device to the sensor to allow the temperature to equilibrate.

Step 3. Turn on and activate your device

1. Wait to receive an email from BerlingerUSA confirming that the data plan has been activated and the device settings are ready to be delivered to each device.
2. To get the settings updated from the Berlinger server, hold down the SET button until NeT ConF appears on the LCD. It will be blinking. Once the settings are updated, it will stop blinking and a check mark will appear momentarily. After about a minute the screen will go blank. You can then proceed to the next step.
3. To activate the Fridge-tag® 3, attach the external sensor and then hold down both the SET and READ buttons until information is displayed on the LCD (about 3 to 4 seconds). You then press the SET button twice. The first time to choose SET DATE (the date is automatically set based on the time zone chosen in the settings profile), and the second time is to accept the date/ time and return the device to the STATUS screen. The activation is now complete.
4. Provide the phone number of each device to each of the users along with an assigned name for each of the storage units. Each user should create a contact in their smart phone for each of the storage units using the name that you have given to it.
5. Send a test SMS to each of the storage units. Open your messaging app, select the storage cabinet and type STATUS and push send. You should get a reply in about minute.

For more information on the Fridge-tag® 3 and installation **click here** to download the full Fridge-tag® 3 Manual: http://www.berlinger.com/fileadmin/user_upload/temperature-monitoring/training_and_support/user_manuals/fridge_tag_3/User_Manual_Fridge-tag_3_EN.pdf